

PatchMaster

MIDI Implementation Chart

Function		Transmitted	Recognised	Remarks
Basic Channel	Default Changed	1-16	1-16	
Mode	Default Messages Altered	O	O	
Note Number	True Voice	O	O	
Velocity	Note On Note Off	O O	O O	
Aftertouch	Key Channel	O O	O O	
Pitch Bend		O	O	
Control Change		O	O	
Program Change		O	O	
System Exclusive		O	O	
System Common	MTC Song Position Song Select Tune	X O O O	X O O O	
System Real Time	Clock Commands	X O	X O	
Aux Messages	Local ON/OFF All Notes Off Active Sense Reset	O O X X	O O X X	

Notes: All MIDI messages except MTC, Clocks, Active Sensing and Reset may be recorded into User Defined Events

O : Yes
X : No

PatchMaster

MIDI Program Changes

	BANK A1	BANK A2	BANK A3	BANK A4	BANK A5	BANK A6	BANK A7	BANK A8
1	1	9	17	25	33	41	49	57
2	2	10	18	26	34	42	50	58
3	3	11	19	27	35	43	51	59
4	4	12	20	28	36	44	52	60
5	5	13	21	29	37	45	53	61
6	6	14	22	30	38	46	54	62
7	7	15	23	31	39	47	55	63
8	8	16	24	32	40	48	56	64

	BANK B1	BANK B2	BANK B3	BANK B4	BANK B5	BANK B6	BANK B7	BANK B8
1	65	73	81	89	97	105	113	121
2	66	74	82	90	98	106	114	122
3	67	75	83	91	99	107	115	123
4	68	76	84	92	100	108	116	124
5	69	77	85	93	101	109	117	125
6	70	78	86	94	102	110	118	126
7	71	79	87	95	103	111	119	127
8	72	80	88	96	104	112	120	128